


ZXV10 B866V2K RichMedia Box

Quick Start Guide



SERVIMAT SAS





ZAET les Haïes
Rue Albert Einstein
60740 - Saint Maximin
FRANCE
www.servimat.fr
Assistance : sav@servimat.fr



Scan the QR code to obtain the complete user manual

Chapter 1


Packing List

Quantity	Item	
1	MEDIA BOX	
1	Remote control	
2	AAA battery	
1	HDMI cable	
1	Power adapter	-
1	Quick Start Guide	-

Notes:

This packing list is for reference only. The items actually delivered depend on the companion packing list of the STB. Contact the provider immediately if parts are missing or damaged. Keep all packaging and available components for return purposes.


CONNEXIONS



Notes:

- Make sure use the +12V DC power adapter that is delivered with the STB.
- Make sure the connection to the STB is correct and that all cables are fully inserted and use the accessories delivered with the STB.

Remote Control



Notes:

- The remote control is powered by two AAA batteries. Insert two AAA batteries into the remote control according to the polarity instruction displayed on it.
- Press and at the same time for 4 seconds, the Remote Control enters pairing mode.
- The remote control works on the infrared mode by default. When the Bluetooth pairing is successful, the infrared function will be closed.
- When the infrared function works, point the front part of the remote control to the infrared receiving area on the STB during the operation.